

## Snocone Machine (110 volt, 7 amps)

## **Operational Instructions:**

- 1. Plug in machine. Keep in mind these units should be on their own 20 amp circuit. We recommend that you do not use an extension cord. If you are going to use an extension cord, please make sure it is heavy duty (at least 12 gauge) 25' extension cord.
- 2. Turn on the light switch.
- 3. Turn on the motor. Some machines have a switch to turn on and off, and some have a button you need to keep pressure on in order for motor to be engaged.
- 4. Fill the gooseneck with ice cubes or block ice broken into 3"x4" pieces about an inch or so from the top, push the pusher handle down to press the ice against the cutterhead. A firm even pressure is all that is required, but sometimes you will find it better to relieve the pressure two or three times on the way down. This lets the ice rearrange itself. Do not force the handle too much because the motor could be staled. Firm pressure is needed for the best snow. If you do too much pressure you get coarse ice and too little pressure gets you mushy ice.
- 5. In normal operations, the motor gets warm which will give you a surface temperature of 150 degrees, which is normal.
- 6. Put only ice in the gooseneck to prevent damage to the blades.
- 7. Keep fingers away from shaver body when motor is running to prevent injury.
- 8. Do not allow any metal to get down in the gooseneck or it will ruin the blade.

\*\*Please do not allow the ice to pile up below the discharge shoot. This will jam the machine. Should this occur, clear out ice with a piece of wood. Do not use your hand! **MAKE SURE MOTOR IS TURNED OFF**, then allow remainder to melt out.

## **Cleaning Instructions:**

- 1. Unplug the machine.
- 2. Wipe all surfaces clean.
- 3. Please return all parts supplied with the machine to avoid additional charges!
  - Pumps
  - Cone storage sleeve rack (1)
  - Sno cone display rack (1)
  - Scoops (large & small)
  - Water tray and hose



**Canton Chair Rental** 4850 Southway St SW Canton, OH 44706 330-477-7719 • 1-800-686-4331 After Hours Pager 330-737-1227 www.cantonchairrental.com

## **Please return** all parts with this machine including the syrup pumps!