



Canton Chair Rental

4850 Southway St SW Canton, OH 44706
330-477-7719 • 800-686-4331
After Hours Pager: 330-737-1227
www.cantonchairrental.com

40 Cup Hot Water Maker

1. Do NOT use this urn for anything but hot water.
2. Pour cool or previously heated water into the urn to fill at least half of the total capacity of the urn.
3. Plug the cord into the electric outlet and turn the power switch "ON", the lamp in the switch should light up now.
4. When the indicator lamp lights up, the water is at proper temperature for hot beverages. (cool water should take about 1 minute per cup to heat , so 20 to 40 minutes)
5. When there are only about 3 cups of water in left in the urn, please turn the power switch "OFF" and unplug the cord from the electric outlet.
6. Please empty remaining water from urn and place it with lid back into the box/container you received it in for return. Thank you.



Canton Chair Rental

4850 Southway St SW Canton, OH 44706
330-477-7719 • 800-686-4331
After Hours Pager: 330-737-1227
www.cantonchairrental.com

40 Cup Hot Water Maker

1. Do NOT use this urn for anything but hot water.
2. Pour cool or previously heated water into the urn to fill at least half of the total capacity of the urn.
3. Plug the cord into the electric outlet and turn the power switch "ON", the lamp in the switch should light up now.
4. When the indicator lamp lights up, the water is at proper temperature for hot beverages. (cool water should take about 1 minute per cup to heat , so 20 to 40 minutes)
5. When there are only about 3 cups of water in left in the urn, please turn the power switch "OFF" and unplug the cord from the electric outlet.
6. Please empty remaining water from urn and place it with lid back into the box/container you received it in for return. Thank you.