



Canton Chair Rental

4850 Southway St SW Canton, OH 44706

330-477-7719 • 1-800-686-4331

After Hours Pager: 330-737-1227

www.cantonchairrental.com

Hot Box Operating Instructions

5143 Insulated Hot Box

How to install unit:

1. Place cabinet near warm ovens. Do NOT place cabinet in drafty areas or near ventilating systems.
2. Plug end into proper wall outlet (120 volts, 2000 watts, 16.6 amps, 60 hertz)
***Keep in mind, each box should be on its own 20 amp circuit for each box. We recommend that you do not use an extension cord. Plug directly into the outlet. If you are going to use an extension cord, please make sure it is heavy duty (at least a 12 gauge), 25' extension cord.**

How to Hold:

1. Push switch to ON.
2. Turn Air Thermostat to No. 10.
3. Preheat cabinet for 30 minutes.
4. Turn Air Thermostat to temperature needed.
5. Put food in cabinet.
NOTE: Proper food holding temperature is 140 degrees or higher.

Shelf Arms:

These may be removed if more space is needed between shelves. Be sure that all shelf arms are returned with hot box.

To Turn Unit Off:

1. Push switch off.

Cleaning Instructions:

1. Wipe up spills as soon as possible.
2. Wipe down inside and outside of cabinet. Wash trays with soap and water or run through the dishwasher before returning to Canton Chair Rental.
3. Please return all parts supplied with box to avoid additional charges!